




PARTS LIST FOR MODEL SV5000



KEY

NO. DESCRIPTION

| | |
|------|--------------------------------|
| 1 | HOUSING |
| 8 | Main Gear Assembly |
| 8A | Main Gear Shim |
| 15 | Handle Assembly |
| 19 | Pinion Gear |
| 20 | Ball Bearing(3req.) |
| 21 | Collar |
| 21A | Bearing Mounting Screw(3 req.) |
| 21B | Ball Bearing Fixed Washer |
| 22 | Bail Arm Cover Screw |
| 22A | Side Cover Screw |
| 22B | Side Cover Screw |
| 24 | Bail Wire |
| 27 | Rotor Cup |
| 27A | Bail Pivot Cover |
| 27E | Balance Weight |
| 28 | Trip Lever |
| 29 | Spring |
| 31 | Bail Arm Screw |
| 31A | Bail Wire Screw |
| 32 | Bail Spring |
| 34 | Bail Arm |
| 34B | Pivot Guide |
| 34C | Pivot Arm |
| 35 | Line Roller |
| 35A | Line Roller Ball Bearing |
| 35B | Line Roller Bushing |
| 36 | Bail Stud Screw |
| 38 | Rotor Nut |
| 38A | Rotor Nut Screw |
| 39 | Spool Shaft |
| 40B | Click Ratchet |
| 43 | Crosswind Block |
| 44 | Crosswind Block Screw |
| 45 | Housing Cover |
| 46 | Housing Cover Screw(3 req.) |
| 47 | Spool Assembly |
| 49 | Spool Click Spring |
| 51 | Retaining Ring |
| 52 | Drag Knob |
| 56 | Friction Drag Washer(3req.) |
| 57 | Keyed Washer(2 req.) |
| 58 | Drag Washer Earred |
| 60 | Thrust Washer |
| 98 | Clutch Retainer |
| 132 | Roller Washer |
| 226 | Rear Cap |
| 226A | Rear Cap Screw |
| 227 | Cam Cover |
| 231 | Crosswind Gear |
| 231B | Crosswind Gear Screw |
| 233 | Bearing Cover |
| 233A | Bearing Cover Washer |

PART

NO.

| | |
|------|--------|
| 001 | 5000SV |
| 008 | 5000SV |
| 008A | 5000CV |
| 015 | 5000SV |
| 019 | 5000SV |
| 020 | 5000CV |
| 021 | 5000SV |
| 021A | 2000SV |
| 021B | 5000SV |
| 022 | 2000SV |
| 022A | 2000SV |
| 022B | 2000SV |
| 024 | 5000SV |
| 027 | 5000SV |
| 027A | 5000SV |
| 027E | 5000SV |
| 028 | 5000SV |
| 029 | 4000SV |
| 031 | 2000SV |
| 031A | 2000SV |
| 032 | 5000SV |
| 034 | 5000SV |
| 034B | 5000SV |
| 034C | 5000SV |
| 035 | 4000SV |
| 035A | 2000CV |
| 035B | 2000SV |
| 036 | 4000SV |
| 038 | 5000CV |
| 038A | 2000CV |
| 039 | 5000SV |
| 040B | 5000CV |
| 043 | 5000SV |
| 044 | 2000SV |
| 045 | 5000SV |
| 046 | 2000SV |
| 047 | 5000SV |
| 049 | 2000CV |
| 051 | 2000CV |
| 052 | 5000SV |
| 056 | 2000CV |
| 057 | 2000CV |
| 058 | 2000CV |
| 060 | 5000CV |
| 098 | 5000SV |
| 132 | 2000CV |
| 226 | 5000SV |
| 226A | 2000SV |
| 227 | 5000SV |
| 231 | 5000SV |
| 231B | 5000SV |
| 233 | 2000SV |
| 233A | 2000SV |